User Manual TEMP Protector

Climate
The TEMP protector, your room under constant control by guarding the temperature.

How it works
The TEMP controller is the ideal means to guard the temperature in your room. The system ensures that the temperature doesn't exceed the set maximum. By switching the TEMP controller through an adjustable thermostat the TEMP Protector can be set at a certain temperature level.
Should the temperature exceed the programmed temperature the TEMP protectore wil shut down the installation (or that part that is connected to it; normally half the installation / lights is connected) to control the temperature. By connecting a SMS Alarm system you can also receive a text message on you mobile phone should your installations / lights be shut down.

The TEMP protector will have to be reset manually.

Connecting the TEMP controller
Unpack the TEMP controller and plug the device into an earthed socket. Connect the thermostat through the jack plug.
Connect the switch board / relais box to the TEMP protector. Maximum capacity 3200 Watt! Exceding the maximum capacity will cause irreversable damage!
Attention: all appliance connected after the TEMP protector will be shut down when the set temperature is exceeded! So do not plug your time swithes After the TEMP controller.
(Schedule is attached)

User instructions for the TEMP controller
Plug the TEMP protector into an earthed socket. Turn the thermostat to the desired temperature. As soon as the temperature exceeds the set temperature the TEMP protector will shut down all appliances connected to it.
Use the reseet button after shut down te reset the installation.

Gebrauchsanleitung TEMP Protector

Klima
Der TEMP protector, Ihr Raum dauernd unter Kontrolle mittels Überwachung der Temperatur.

Die Wirking
Der TEMP controller ist die ideale Überwachung für Temperaturbeherrschung in einem Raum. Das System sorgt dafür das die Temperatur im Raum nicht zu hoch wird. Mittels einstallbares Thermostat wird der TEMP protector auf die maximum Temperatur eingestellt.
Sollte dieses eingestellte Maximum überschritten werden wird der TEMP protector die Installation (oder ein Teil davon; abhängis was angeschlossen ist) ausschalten. Ausserdem können Sie unser SMS Alarm System anschliessen; beim ausschalten der Lampen bekommen Sie dann ein Textbericht auf Ihr Handy.

Der TEMP protector muss handmässig reset werden.

Anschliessen der TEMP protectors
TEMP protector auspacken und anschliessen in eine geerdete Steckdose.
Schliessen Sie den Thermostat mittels Jack Plug an. Schliessen sie den Relais-Box auf dem TEMP protector an. **Maximal Kapazität 3200 Watt.**
Überforderung hat unersetzlichen Schaden zu Folge!
Achtung: alle Geräte die nach den TEMP protector geschaltet sind werden ausgeschaltet wenn die Temperatur das eingestellte Maximum überschreitet!
Achtung Sie darauf dass Sie Ihre Zeituhren nicht nach den TEMP protector anschliessen.
(Plan ist eingeschlossen)

Bedienung des TEMP controllers
Stecken Sie den TEMP protector in eine geehrte Steckdose und drehen Sie den Thermostat auf die gewünschte Temperatur. Wenn die Temperatur das eingestellte Maximum überschreitet wird der TEMP protector den Strom zu angeschlossene Geräte abschliessen.
Mit dem Reset Knopf auf dem TEMP Protector wird alles, nach einer Ausschaltung, wieder reset werden.